

## Metal Mitre Tools

### METAL MITRE TOOLS

<b>Order No.</b>	<b>Description</b>
1840-C	Handle Clamp
1845-A	Handle & Spring Assembly
1845-B	Locker w/Fastener
1845-F	Torsion Spring
1845-G	Die Set Holding Screws (2)
1846-A	Replacement Punch (.135" Thick)
1846-B	Die Shoe Only
1846-C	Punch Holder Screws (2)
1846-D	Punch Holder
1846-H	Springs (2)
1848-A	Replacement Punch (.090" Thick)
1850-A	Replacement Punch (.050" Thick) (Comes w/Pressure Pad)
1870-A*	Replacement Punch (.156" Thick)
1870-B*	Die Shoe Only

\* 1870-A and 1870-B must be sold as a matched set

### METAL MITRE NOTES:

1846-A is a .135" thick punch for use on carpet cap and wall board cap. This punch is too thick to enter narrow channels of laminate and vinyl cap metals.

1848-A is a relieved punch with a thickness of .090". For use on most vinyl and carpet cap metals with at least a 3/32" opening.

1850-A is a 0.050" thick punch. Slender punch for use on vinyl and laminate cap with at least a 1/16" opening. Comes with replacement pressure pad.

No. 1870-A is a .156" thick punch for use with No. 870 replacement punch ONLY! Nos. 1870-A and B are not interchangeable. Used to notch vinyl moldings for tight radius bends without wrinkles.

All punches are interchangeable except No. 1870-A & B.

