

No. 700 Bearcat Floor Stripper

NO. 700 BEARCAT FLOOR STRIPPER

Order No.	Description
1700-A	Channel Base Frame Assembly
1700-B*	3/4 HP Motor w/Fasteners
1700-B1	Motor Wire Box Only
1700-BF	Motor Fasteners Only
1700-C	Shaft Key
1700-D	Eccentric
1700-E*	Shaft Bearing w/Fasteners
1700-F*	Shaft Collar w/Fasteners
1700-G	Main Oilite Bearing Plate w/Fasteners (Discontinued)
1700-GS	Main Bearing Plate Nut & Bolt
1700-H	Blade Holder Base Assembly (Discontinued)
1700-I	Blade Holder w/Fasteners
1700-IS	Blade Clamp Fasteners Only (2)
1700-J	Round Oilite Bearing & Spring
1700-K	Switch Only
1700-L*	Retaining Plate w/Fasteners
1700-M	Upper Handle & Grips
1700-N*	Square Washer Set w/Fasteners
1700-O	Handle Lock
1700-P	Switch Box Assembly
1700-Q	Wheel Set
1700-QO	Wheel Spacer Only
1700-QS	Wheel Lock Nut Only
1700-R	Wheel Support Arm Assembly
1700-S	Wheel Adjusting Knob
1700-T	Wheel Adjusting Arm
1700-U	Vector Arm w/Fasteners
1700-UF	Vector Arm Fasteners Only (2)
1700-V	Motor Cover
1700-W	Motor Fan
1700-X	Capacitor Cover
1700-Y	Capacitor
1700-Z	Hex Key Wrench
1701-A	Long Vector Arm w/Fast (Old) (Discontinued)
1701-AS	Long Vector Arm Fasteners Only

* For fasteners only, please call.



NOTE - The following part is discontinued:
1701-A Long Vector Arm w/Fast. (Old Style)
But fasteners are still available:
1701-AS Long Vector Arm Fasteners Only

